



Ersatzteile

AS 800 FreeRider

- from serial No. 030017100001

Seriennummer, Сериен номер, Sériové číslo, Serial number, Número de serie, Sarjanumero, Numéro de série, Serijski broj, Sorozatszám, Numero di serie, Serijos numeris, Seriennummer, Numer seryjny, Serijska številka

DE Hier Aufkleber aus Garantiekarte aufkleben.
BG Залепете тук стикери от гаранционната Карта.
CZ Sem nalepte nálepku ze záručního listu.
DK Her skal maerkaten fra garantikortet klæbes på.
GB Please adhere the sticker from the warranty card here.
ES Pegar aquí el adhesivo de la tarjeta de garantía.
FI Liimaa takuukortin tarra tähän.
FR Collez ici l'autocollant placé sur la carte de garantie.
HR Ovdje zalijepite naljepnicu iz jamstvenog lista.

HU Ide ragassza a matricát a garanciakártyából.
IT Applicare qui l'etichetta, come scheda di garanzia.
LT Čia užklijuokite garantijos pase pateiktą lipduką.
NL Plak hier sticker uit garantiekaart.
NO Lim klistremerke fra garantikortet inn her.
PL Tutaj nakleść naklejkę na kartę gwarancyjną.
SL Tukaj nalepite nalepko z garancijskega lista.
SE Klistra fast etiketten från garantikortet här.

Ab Serien Nr.: from serial No. 030017100001

Ausgabe: 20.01.2026, EN

AS-Motor GmbH
Ellwanger Straße 15
D-74424 Bühlertann
Telefon 07973-9123-0
Telefax 07973-9123-259
www.as-motor.de

If you need spare parts:

1. Send your order to your AS-Motor dealer.
2. In order to get you the right spare part he needs:

- **Model name (s. sticker on the machine)**
- **Serial No. of machine (sticker or S/N lable)**
- **Articlenumber**
- **Your dealer orders part in our online system parts and more.**


Only in this case you receive all important information about proper spare parts and possible technical changes.

Please fulfil only maintenance tasks mentioned in the owner manual by yourself. All other tasks have to be done by authorised AS-Motor dealer.

Subject to change without notice.

Images may show differences from the machines in production.


Engine with belt drive



Engine with belt drive

Item	Part-No.		Quantity	Description
30	G00007042	E06037	0	Selflocking nut with serrated bearing (3
51	G00007041	E05975	0	Selflocking nut with serrated bearing (5
64	G07809004	E01905	0	Disc (20 Stk.)
67	G07838044	E05609	0	Hexagon screw (5 Stk.)
81	G07880006	E03957	0	Disc (20 Stk.)
116	G07838026	E03932	0	Hexagon screw (10 Stk.)
136	G00009016	E04631	0	Hexagon screw with serration (5 Stk.)
148	G06825009	E08418	0	Engine hub with belt pulley
149	G04425004	E04286	0	Belt pulley half
150	G04425005	E04287	0	Compensating spacer (4 Stk.)
151	G07890005	E04986	0	Flanged self-tapping screw (3 Stk.)
152	G07865010	E06713	0	Feather key
153	G00010106	E07879	0	Drive pulley
154	G00009066	E06716	0	Inch screw (2 Stk.)
155	G06825024	E08432	0	Pulley half Ø 135
156	G06825003	E08511	0	Tensioning roller carrier total
157	G00028027	E06473	0	DU bush
158	G06525063	E07208	0	Tension pulley with ball bearing
159	G07830025	E06524	0	Deep groove ball bearing
160	G07823016	E07209	0	Circlip for drilled hole (2 Stk.)
161	G06525057	E07176	0	Tensioning roller sleeve
162	G07838047	E05320	0	Hexagon screw (10 Stk.)
163	G06525054	E07158	0	Tension lever bearing
164	G07857032	E08216	0	High performance V-belt
165	G07857035	E08304	0	High performance V-belt
166	G00002011	E04343	0	Draw spring
167	G06825025	E08453	0	Belt support
168	G07827003	E04262	0	Mushroom head square neck bolt (5 Stk.)
169	G07834009	E08512	0	Threaded pin (5 Stk.)
170	G00509025	E08427	0	Exhaust
171	G00009106	E08095	0	Inch screw (2 Stk.)
172	G06826015	E08461	0	Engine lid
357	G00501038	E13093	0	Engine B&S INTEK 3
358	G00501037	E13088	0	Engine B&S POWER BUILT 3
364	G06880012	G06880012	0	Gas lever+bowden cable+handle+screws
365	G00008207	G00008207	0	Handle
366	G07875010	E05756	0	Raised cross-head sheet metal screw (10

Proposal for wear parts list




1 → Alle Artikel in den Warenkorb legen / Put all items in the cart / Mettre tous les articles dans le panier / Pon todos los artículos en el carrito / Поместить все запасные части в корзину

Bei Bedarf Artikel in der Zeichnung ansehen / If necessary, see the article in the drawing / Si nécessaire, regarder l'article dans l'éclaté / Si es necesario, ver el artículo en el dibujo / При необходимости см. запасную часть на чертеже:

2 → Klick auf Fernglas / Click on binoculars / Cliquez sur les jumelles / Haga clic en binoculares / Нажмите на бинокль

3 → Klick auf Artikel-Nummer bei Gerätemodell / Click on item number at according device model / Cliquez sur le numéro de pièce dans le modèle d'appareil / Haga clic en el número de artículo en el modelo de máquina / Нажмите на номер товара для модели устройства



Proposal for wear parts list

Item	Part-No.		Quantity	Description
1	G07857035	E08304	1	High performance V-belt
2	G06823005	E08405	1	Mulching blade 434
3	G06880002	E08343	1	Blade AS 800 with bolts
4	G06734001	E07699	1	Brake lever with lining and DU bush
5	G07857032	E08216	1	High performance V-belt

Proposal repair parts list

Stückliste: Verschleißteilliste

Pos	Art.-Nr.	Art.-Nr. (bisher)	Menge (min.)	Beschreibung	Info	Modell	Preis	% => €	Tech-Info
1	G90180003	G90180003	28 (1)	Schlegelmesser mit Befestigung					bearbeiten
2	G07857057	G07857057	1 (1)	Keilriemen					bearbeiten
3	G07857056	G07857056	1 (1)	Keilriemen					bearbeiten
4	G07857035	E08304	1 (1)	Hochleistungskeilriemen					bearbeiten
5	G90434008	G90434008	1 (1)	Bremsbelaghalter mit Bremsbelag					bearbeiten
6	G00041064	E12381	1 (10)	2x5L Kanister Öl Titan Supersyn SAE5W-50					bearbeiten
7	G00006067	G00006067	1 (1)	O-Ring					bearbeiten
8	G06990016	E11741	1 (1)	Dichtscheibe 10					bearbeiten
9	G06980002	E11530	1 (1)	Ölfitter+Deckel+Dichtungen					bearbeiten
10	G00006066	G00006066	1 (1)	O-Ring					bearbeiten

1 → Alle Artikel in den Warenkorb legen / Put all items in the cart / Mettre tous les articles dans le panier / Pon todos los artículos en el carrito / Поместить все запасные части в корзину

Bei Bedarf Artikel in der Zeichnung ansehen / If necessary, see the article in the drawing / Si nécessaire, regarder l'article dans l'éclaté / Si es necesario, ver el artículo en el dibujo / При необходимости см. запасную часть на чертеже:

2 → Klick auf Fernglas / Click on binoculars / Cliquez sur les jumelles / Haga clic en binoculares / Нажмите на бинокль

3 → Klick auf Artikel-Nummer bei Gerätemodell / Click on item number at according device model / Cliquez sur le numéro de pièce dans le modèle d'appareil / Haga clic en el número de artículo en el modelo de máquina / Нажмите на номер товара для модели устройства

Proposal repair parts list


Item	Part-No.		Quantity	Description
1	G06650952	E11015	1	Ignition key
2	G00020122	E08373	1	Blade drive cable
3	G06826002	E08401	1	Protection skirt
4	G00008115	E08404	1	Ejector rubber
5	G06822032	E08419	1	Replaced by G06880012
	G06880012	G06880012	1	Gas lever+bowden cable+handle+screws
6	G00020123	E08374	1	Differential cable
7	G00020124	E08375	1	Brake pedal cable

Electrical system

Elektrische Anlage

AS 800 ab Serien Nr. 0160 10 09 0005 bzw. 0300 17 10 0001

AS 799 ab Serien Nr. 0266 13 08 0001 bzw. 0301 17 10 0001




Electrical system

Item	Part-No.		Quantity	Description
43	G06850039	E08542	1	Battery
45	G07838078	E08505	4	Hexagon screw (10 Stk.)
46	G07839007	E01950	4	Hex nut (10 Stk.)
47	G00010110	E08529	2	Replaced by G07809003. (5 Stk.)
53	G07809003	E01181	2	Disc (20 Stk.)
48	G07811006	E01908	2	Spring washer (20 Stk.)
49	G07838015	E03959	1	Hexagon screw (10 Stk.)
50	G07809006	E01940	3	Disc (10 Stk.)
51	G00007041	E05975	3	Selflocking nut with serrated bearing (5
61	G00008117	E08530	1	Rubber band
74	G06650532	E08160	1	Seat contact switch
87	G06927006	E08536	2	Replaced by G00049003
88	G00047003	G00047003	2	Push button (NO contact)
90	G07838064	E07628	2	Hexagon screw (2 Stk.)
91	G00007058	E08539	2	Inch nut (5 Stk.)
92	G07809003	E01181	2	Disc (20 Stk.)
93	G07802039	E04866	2	Cylinder screw (5 Stk.)
94	G07809002	E01109	6	Disc (10 Stk.)
95	G07846016	E08540	4	Self-locking hex nut (5 Stk.)
96	G07878021	E08541	2	Raised cross-head screw (3 Stk.)
105	G06650539	E08173	1	Fuse 25 A (alternator)
106	G06650354	E07564	1	Fuse 15 A (Main fuse)
343	G06850048	E11017	1	Cable loom
344	G06650817	E10659	1	Relay
345	G06927007	E10660	1	Relay large
347	G06650951	E11014	1	Ignition switch without key
348	G06650952	E11015	1	Ignition key

Blade cover

AS 800 / AS 799 Messerhaube




Blade cover

Item	Part-No.		Quantity	Description
30	G00007042	E06037	8	Selflocking nut with serrated bearing (3
51	G00007041	E05975	12	Selflocking nut with serrated bearing (5
136	G00009016	E04631	6	Hexagon screw with serration (5 Stk.)
168	G07827003	E04262	2	Mushroom head square neck bolt (5 Stk.)
178	G07880001	E01980	2	Disc (10 Stk.)
265	G06820005	E08383	1	Blade hood
266	G06820008	E08406	1	Hood carrier
267	G04526018	E06907	1	Spacer pin
269	G06525312	E06653	1	Belt support
270	G07827018	E08387	8	Mushroom head square neck bolt (10 Stk.)
271	G06826001	E08398	1	Belt cover
272	G06826016	E08468	1	Access protection
273	G07827008	E04991	12	Mushroom head square neck bolt (3 Stk.)
274	G06822005	E08399	2	Fork head counter piece
275	G07838025	E03930	2	Hexagon screw (5 Stk.)
276	G06820016	E08470	1	Hood corner right
277	G06820015	E08469	1	Hood corner left

Protector cloth

AS 800 / AS 799 Schutztücher



Protector cloth


Item	Part-No.		Quantity	Description
136	G00009016	E04631	7	Hexagon screw with serration (5 Stk.)
243	G00010084	E03710	2	Disc (10 Stk.)
252	G07906002	E06667	11	Self-locking hex nut (10 Stk.)
317	G06826002	E08401	1	Protection skirt
318	G06826003	E08402	1	Protection skirt tube
319	G00034023	E07177	5	Clip
320	G00008115	E08404	1	Ejector rubber
321	G06820018	E08471	1	Rubber bar
322	G07827010	E05367	4	Mushroom head square neck bolt (5 Stk.)

Front axle

Item	Part-No.		Quantity	Description
17	G06850010	E08492	1	Bearing washer
18	G06850011	E08493	1	Toothed plate
19	G00009116	E08494	1	Locking screw
20	G06850012	E08495	1	Unscrew protection
22	G07839003	E01906	1	Hex nut (10 Stk.)
23	G00007051	E07668	1	Locknut (2 Stk.)
24	G07861007	E08496	2	Disc
25	G06850013	E08497	2	Steering rod with 2 ball joints
26	G06850014	E08498	1	Front axle
27	G06650152	E07333	4	Bush
28	G07903002	E05868	2	Lubricating nipple (3 Stk.)
29	G07838031	E03951	2	Hexagon screw (5 Stk.)
30	G00007042	E06037	2	Selflocking nut with serrated bearing (3
31	G06850015	E08499	1	Axle sleeve
32	G07837072	E08500	1	Hexagon screw
33	G07809010	E03592	2	Disc (10 Stk.)
34	G07918005	E07672	1	Self-locking hex nut
35	G06850017	E08501	1	Axle leg left
36	G06850016	E08502	1	Axle leg right
37	G00042017	E08503	4	Lock washer (5 Stk.)
39	G06650443	E07997	1	Left hand front wheel 13X5.00-6
40	G06650442	E07996	1	Right hand front wheel 13X5.00-6
41	G07847028	E08504	4	Shim (5 Stk.)
42	G07822012	E07552	4	Circlip for shaft (2 Stk.)
50	G07809006	E01940	12	Disc (10 Stk.)
110	G06650153	E07334	2	Cover
114	G07838029	E03939	1	Hexagon screw (5 Stk.)
118	G06650438	E07992	2	Rim for front wheel
119	G06650441	E07995	2	Distance sleeve
120	G07830019	E04737	4	Deep groove ball bearing
121	G07838013	E02949	12	Hexagon screw (10 Stk.)
122	G07839014	E03915	12	Hex nut (20 Stk.)
123	G06650439	E07993	2	Tube for front wheel
124	G06650440	E07994	2	Cover for front wheel
334	G07846005	E01968	4	Self-locking hex nut (10 Stk.)

Adjustment of cutting height

AS 800 / AS 799 Verstellung der Schnitthöhe




Adjustment of cutting height

Item	Part-No.		Quantity	Description
30	G00007042	E06037	6	Selflocking nut with serrated bearing (3
38	G07839008	E01953	4	Hex nut (10 Stk.)
42	G07822012	E07552	1	Circlip for shaft (2 Stk.)
64	G07809004	E01905	2	Disc (20 Stk.)
111	G00009108	E08177	4	Hexagon screw with serration (3 Stk.)
112	G00010133	E12385	4	Disc
116	G07838026	E03932	4	Hexagon screw (10 Stk.)
157	G00028027	E06473	1	DU bush
163	G06525054	E07158	1	Tension lever bearing
202	G06822002	E08421	2	Lifting arm total
203	G00028031	E07222	4	Friction bearing
204	G06822028	E08442	1	Lifter lever holder total
205	G06822025	E08436	1	Lifter lever holder
206	G06822027	E08443	1	Deflection lever total
207	G00010109	E08394	1	Mudguard washer (5 Stk.)
208	G07861006	E07940	7	Disc
209	G06522316	E07160	4	Bar bolt
210	G07837015	E03777	4	Hexagon screw (5 Stk.)
211	G06822024	E08428	1	Lifter brace
212	G06822010	E08407	1	Retractable axle total
213	G06822030	E08447	1	Height adjustment lever total
214	G06822023	E08522	1	Height adjustment lever
215	G00008116	E08523	1	Lever cover
216	G06526002	E06726	1	Connection nut
217	G07838019	E03886	1	Hexagon screw (10 Stk.)
218	G07833028	E08446	1	Hexagon socket head cap screw
219	G00028038	E08445	2	Friction bearing with collar
220	G06822029	E08444	1	Adjusting lever pin
221	G00028039	E08448	2	Friction bearing
222	G06822012	E08408	1	Replaced by G06922034
	G06922034	E11613	1	Lifter rod total
223	G07839022	E08282	2	Hex nut
232	G06822004	E08400	2	Lifting rod total
233	G00039004	E08467	4	Folding spring bolt

Blades with drive

AS 800 Messer mit Antrieb




Blades with drive

Item	Part-No.		Quantity	Description
7	G07822001	E02116	1	Circlip for shaft (5 Stk.)
30	G00007042	E06037	8	Selflocking nut with serrated bearing (3
165	G07857035	E08304	1	High performance V-belt
251	G07838027	E03933	6	Hexagon screw (10 Stk.)
252	G07906002	E06667	6	Self-locking hex nut (10 Stk.)
280	G07830015	E08351	3	Deep groove ball bearing
282	G06723007	E07707	1	Cutter disc
283	G07865021	E08293	1	Feather key
284	G07847015	E03928	1	Supporting disc
285	G07827017	E06612	8	Mushroom head square neck bolt (3 Stk.)
286	G06825017	E08396	1	Belt pulley total
287	G06825004	E08397	1	Belt pulley complete
288	G06725004	E07531	1	Belt pulley hub
289	G07865011	E06649	1	Feather key
290	G07861004	E07213	1	Disc (2 Stk.)
291	G00009097	E07718	2	Locking screw (4 Stk.)
292	G06723006	E07262	1	Winding protection cover
293	G06823005	E08405	1	Mulching blade 434
294	G06880002	E08343	1	Blade AS 800 with bolts
295	G00009111	E08291	1	Locking screw
354	G06880009	E13092	1	Blade bearing with shaft+bearing
355	G06823006	E13091	1	Blade baring
356	G06723015	E13096	1	Blade shaft

Differential lock

AS 800 Differentialsperre




Differential lock

Item	Part-No.		Quantity	Description
21	G07838028	E03938	4	Hexagon screw (10 Stk.)
30	G00007042	E06037	6	Selflocking nut with serrated bearing (3
51	G00007041	E05975	2	Selflocking nut with serrated bearing (5
64	G07809004	E01905	6	Disc (20 Stk.)
111	G00009108	E08177	2	Hexagon screw with serration (3 Stk.)
112	G00010133	E12385	2	Disc
115	G07846001	E01912	4	Self-locking hex nut (10 Stk.)
120	G07830019	E04737	2	Deep groove ball bearing
135	G00007052	E07876	2	Connection nut (2 Stk.)
136	G00009016	E04631	4	Hexagon screw with serration (5 Stk.)
144	G06725013	E07687	2	Pinion 12 teeth
173	G06825029	E08431	1	Differential panel left
174	G06825028	E08430	1	Differential panel right
175	G00007057	E08437	4	Box nut (5 Stk.)
177	G07827004	E04379	6	Mushroom head square neck bolt (5 Stk.)
178	G07880001	E01980	3	Disc (10 Stk.)
179	G06725312	E08237	2	Bearing plate
180	G06825007	E08417	1	Differential lever total
181	G06825005	E08415	1	Differential lever
182	G06825006	E08416	1	Lever holder
183	G07830031	E07211	5	Deep groove ball bearing
184	G06725305	E08240	1	Clutch total
185	G06725306	E08244	1	Pinion flange
186	G04325096	E05410	1	Pressure plate
187	G00007054	E08241	1	Selflocking nut with serrated bearing
188	G04325093	E05408	2	Inner lamella
189	G04325094	E05409	1	Outer lamellas
190	G04325091	E05407	1	Clutch basket
191	G06725317	E08242	1	Supporting disc
192	G07830014	E04345	1	Deep groove ball bearing
193	G06725315	E08243	1	Clutch flange
194	G07890003	E04576	1	Flanged self-tapping screw (3 Stk.)
195	G06825020	E08429	1	Differential shaft
196	G07865019	E07723	1	Feather key (4 Stk.)
197	G06825030	E08438	1	Chain ring
198	G06820019	E08472	1	Wind deflector panel
201	G00020123	E08374	1	Differential cable

Pedal

AS 800 Pedale




Pedal

Item	Part-No.		Quantity	Description
50	G07809006	E01940	2	Disc (10 Stk.)
81	G07880006	E03957	4	Disc (20 Stk.)
116	G07838026	E03932	4	Hexagon screw (10 Stk.)
157	G00028027	E06473	2	DU bush
163	G06525054	E07158	2	Tension lever bearing
201	G00020123	E08374	1	Differential cable
229	G00012027	E08451	2	Bolt for anti-folding mechanism
230	G00027016	E08452	2	Anti-folding mechanism (5 Stk.)
259	G00020124	E08375	1	Brake pedal cable
261	G06825031	E08423	1	Differential pedal total
262	G06834006	E08422	1	Reset pedal for brake total
338	G06826014	E08856	2	Pedal sticker

Drive wheels with chain drive

AS 800 Antriebsräder mit Kettentrieb




Drive wheels with chain drive

Item	Part-No.		Quantity	Description
125	G06721003	E07700	4	Thrust washer
126	G00010105	E07873	4	Thrust washer
127	G06821004	E08439	2	Wheel sleeve
128	G06721005	E08319	2	Wheel hub total
129	G06721002	E07266	2	Wheel hub
130	G06725012	E07686	2	Pinion 39 teeth
131	G00009085	E06761	18	Hexagon screw (2 Stk.)
133	G06726013	E07885	1	Chain protection left
134	G06726012	E07886	1	Chain protection right
135	G00007052	E07876	4	Connection nut (2 Stk.)
136	G00009016	E04631	10	Hexagon screw with serration (5 Stk.)
137	G00007055	E08289	2	Box nut (5 Stk.)
138	G07865015	E07267	2	Feather key (2 Stk.)
139	G06521011	E06458	1	Wide tyre left 16X6.50-8
140	G06521010	E06457	1	Wide tyre right 16X6.50-8
141	G06550014	E08029	2	Rim for wide tyre
142	G06521014	E06570	2	Tube for wide wheels
143	G06550012	E07684	2	Cover for wide tyre
144	G06725013	E07687	2	Pinion 12 teeth
145	G06821005	E08440	2	Wheel ring
146	G07864009	E08441	2	Lock washer (3 Stk.)
147	G07847046	E07725	1	Shim (3 Stk.)
199	G06525035	E06425	2	Chain joint
339	G06580018	E10819	2	Chain 59 links with lock

Belt tensioner, brake lever and blade lever


AS 800 / AS 799 Riemenstranner, Bremshebel und Messerhebel



Belt tensioner, brake lever and blade lever

Item	Part-No.		Quantity	Description
30	G00007042	E06037	1	Selflocking nut with serrated bearing (3
50	G07809006	E01940	1	Disc (10 Stk.)
51	G00007041	E05975	1	Selflocking nut with serrated bearing (5
63	G07837041	E04944	1	Hexagon screw (3 Stk.)
111	G00009108	E08177	3	Hexagon screw with serration (3 Stk.)
115	G07846001	E01912	1	Self-locking hex nut (10 Stk.)
135	G00007052	E07876	1	Connection nut (2 Stk.)
136	G00009016	E04631	2	Hexagon screw with serration (5 Stk.)
183	G07830031	E07211	2	Deep groove ball bearing
207	G00010109	E08394	2	Mudguard washer (5 Stk.)
208	G07861006	E07940	1	Disc
224	G06822019	E08411	1	Blade engagement lever total
225	G07917001	E07245	1	Spherical button
226	G06822031	E08449	1	Bearing washer
227	G00009114	E08450	1	Raised flat-head screw
228	G07847036	E05984	5	Shim (10 Stk.)
229	G00012027	E08451	1	Bolt for anti-folding mechanism
230	G00027016	E08452	1	Anti-folding mechanism (5 Stk.)
231	G00008061	E04597	1	Stop buffer
248	G07822002	E02650	1	Circlip for shaft (5 Stk.)
252	G07906002	E06667	6	Self-locking hex nut (10 Stk.)
260	G00020122	E08373	1	Blade drive cable
268	G00009094	E07247	1	Locking screw (2 Stk.)
296	G06834001	E08384	1	Brake lever bearing
297	G07818008	E07875	1	Hex nut
298	G06825018	E08385	1	Tension lever bearing
299	G06820010	E08388	1	Spring tube
300	G00001083	E08389	1	Pressure spring
301	G00028037	E08390	1	Friction bearing with collar
302	G07818004	E03917	1	Hex nut (10 Stk.)
303	G07925001	E08526	1	Fork head
304	G00039003	E08527	1	Folding spring bolt
305	G06880001	E08524	1	Belt tensioner + DU bushes
306	G00028001	E02919	2	DU bush (2 Stk.)
307	G06825013	E08392	1	Tension pulley with ball bearing
308	G07830027	E06752	2	Deep groove ball bearing
309	G00009083	E06753	6	Rounded head screw with inside Torx (2 S
310	G06825014	E08393	1	Sleeve
311	G04620002	E06936	1	Mounting bolt
312	G06734001	E07699	1	Brake lever with lining and DU bush
313	G00028022	E06364	1	DU bush
314	G00024029	E07722	1	Sleeve
315	G06825016	E08395	1	Belt guide
316	G00002056	E07867	1	Draw spring
337	G07816006	E04214	1	Disc (20 Stk.)
363	G00041008	E04721	1	LOCTITE 270 (50 ml)


Transmission



Transmission


Item	Part-No.		Quantity	Description
30	G00007042	E06037	9	Selflocking nut with serrated bearing (3
63	G07837041	E04944	4	Hexagon screw (3 Stk.)
64	G07809004	E01905	9	Disc (20 Stk.)
65	G07837016	E03901	1	Hexagon screw (5 Stk.)
176	G07837005	E03142	4	Hexagon screw (4 Stk.)
340	G06880005	E10925	1	Surge tank with cover
341	G06850046	E10926	1	Cover for surge tank
342	G06850049	E10977	1	Impeller
346	G06880006	E11414	1	Belt pulley + safety ring
359	G06880010	E13122	1	Hydrostatic transmission+Belt pulley
359/1	G06850056	G06850056	1	Getriebe (Generalüberholt)
	G06880013	G06880013	1	Part no longer available

Drive lever with brake from serial No. 016014100001



Drive lever with brake from serial No. 016014100001

Item	Part-No.		Quantity	Description
30	G00007042	E06037	4	Selflocking nut with serrated bearing (3
38	G07839008	E01953	1	Hex nut (10 Stk.)
116	G07838026	E03932	1	Hexagon screw (10 Stk.)
131	G00009085	E06761	2	Hexagon screw (2 Stk.)
136	G00009016	E04631	1	Hexagon screw with serration (5 Stk.)
183	G07830031	E07211	1	Deep groove ball bearing
208	G07861006	E07940	1	Disc
221	G00028039	E08448	1	Friction bearing
226	G06822031	E08449	2	Bearing washer
228	G07847036	E05984	4	Shim (10 Stk.)
235	G06822022	E08414	1	Lever shaft
236	G00019050	E03076	1	Slide washer (2 Stk.)
237	G06822021	E08413	1	Drive lever left
238	G06822033	E08455	1	Bearing flange
239	G07830003	E02104	1	Deep groove ball bearing
241	G07856006	E03319	4	Disc spring (10 Stk.)
242	G00007044	E06130	2	Hex nut
243	G00010084	E03710	1	Disc (10 Stk.)
244	G06822034	E08412	1	Drive lever total
245	G00002040	E06475	1	Draw spring
246	G07847011	E03134	1	Shim (10 Stk.)
247	G00028008	E06538	3	DU bush
248	G07822002	E02650	1	Circlip for shaft (5 Stk.)
249	G07917003	E08456	1	Spherical button
250	G06822035	E08458	1	Release lever
251	G07838027	E03933	1	Hexagon screw (10 Stk.)
252	G07906002	E06667	1	Self-locking hex nut (10 Stk.)
253	G00007025	E03706	1	Special nut (10 Stk.)
254	G07837025	E04227	1	Hexagon screw
255	G06822014	E08409	1	Drive rod total
256	G00039005	E08459	1	Folding spring bolt
257	G06822036	E08460	1	Drive lever pin
258	G06834008	E08410	1	Brake rod total
259	G00020124	E08375	1	Brake pedal cable
338	G00009024	E04519	4	Self-tapping screw (3 Stk.)
362	G06834009	E13160	1	Brake bracket


Instruction plate – set from serial No. 016014100001

Pos.Nr.	ET-Nr.	Benennung
2	E13164	Aufkleber - Set AS 800 + AS 799 AS 800 ab Seriennr. 0160 14 10 0001 Aufkleber - Set AS 800 + AS 799 AS 799 ab Seriennr. 0266 14 10 0008

Instruction plate – set from serial No. 016014100001

Item	Part-No.		Quantity	Description
2	G06880011	E13164	1	Instruction plate-set AS800+AS799


Seat with frame from serial No. 030017100001



Seat with frame from serial No. 030017100001

Item	Part-No.		Quantity	Description
1	G06850001	E08433	1	Frame
30	G00007042	E06037	4	Selflocking nut with serrated bearing (3
50	G07809006	E01940	2	Disc (10 Stk.)
74	G06650532	E08160	1	Seat contact switch
107	G06650134	E07315	2	Stopper
108	G06650300	E07481	2	Extension
109	G06650178	E07359	2	Seat spring
117	G00009100	E07874	2	Countersunk screw with inside Torx (3 St
162	G07838047	E05320	2	Hexagon screw (10 Stk.)
371	G06920073	E11660	1	Seat + switch without rails
372	G06920085	E11661	1	Inside rail
373	G06920084	E11662	1	Rail with adjusting lever
374	G06920087	E11663	2	Outside rail
375	G07833049	G07833049	4	Hexagon socket head cap screw (2 Stk.)
376	G07833017	E06276	4	Hexagon socket head cap screw (5 Stk.)
377	G07847018	E04374	4	Shim (10 Stk.)
378	G07926001	E08403	4	Disc (4 Stk.)
380	G07875018	E07950	2	Raised cross-head sheet metal screw (5 S
384	G06820022	G06820022	1	Seat plate


Covers front



Covers front

Item	Part-No.		Quantity	Description
30	G00007042	E06037	7	Selflocking nut with serrated bearing (3
51	G00007041	E05975	2	Selflocking nut with serrated bearing (5
268	G00009094	E07247	8	Locking screw (2 Stk.)
323	G06820014	E08462	1	Base plate
324	G00007046	E06672	6	Box nut (2 Stk.)
367	G06826028	G06826028	1	Front guard
368	G06826029	G06826029	1	Front panel
369	G06826030	G06826030	2	Sheet tab
370	G00009174	E12496	2	Dome head screw with Torx (10 Stk.)
385	G00009189	G00009189	3	Hexagon screw with serration (5 Stk.)


Covers rear from serial No. 030017100001



Covers rear from serial No. 030017100001

Item	Part-No.		Quantity	Description
51	G00007041	E05975	5	Selflocking nut with serrated bearing (5
136	G00009016	E04631	16	Hexagon screw with serration (5 Stk.)
137	G00007055	E08289	2	Box nut (5 Stk.)
175	G00007057	E08437	9	Box nut (5 Stk.)
324	G00007046	E06672	5	Box nut (2 Stk.)
325	G06826011	E08435	1	Side cover left total
326	G06826010	E08434	1	Side cover right total
327	G06826020	E08463	1	Engine cover total
328	G06826024	E08464	1	Ventilation grid
329	G00510002	E06708	4	Angle bracket
330	G00009038	E05720	4	Screw with Torx (3 Stk.)
331	G00009081	E06733	1	Raised-head shouldered screw (4 Stk.)
333	G06826017	E08466	1	Cover rear
349	G07913004	E10189	4	Hexagon screw with flange
350	G06826025	E08857	1	Exhaust sleeve

Tank with steering from serial No. 030017100001



Tank with steering from serial No. 030017100001

Item	Part-No.		Quantity	Description
2	G00027017	E08457	3	Anti-folding mechanism (5 Stk.)
3	G06850002	E08477	1	Tank holder
5	G06850004	E08479	1	Plastic sleeve
6	G07847040	E06304	2	Shim (3 Stk.)
7	G07822001	E02116	1	Circlip for shaft (5 Stk.)
8	G00028040	E08480	1	DU bush
9	G06850005	E08481	1	Pinion
11	G07822015	E08483	1	Circlip for shaft (2 Stk.)
12	G07847049	E08484	1	Shim (2 Stk.)
30	G00007042	E06037	2	Selflocking nut with serrated bearing (3
52	G06680123	E10735	1	Fuel tank total
53	G06850007	E08487	1	Tank plate
54	G07922001	E07666	5	Raised countersunk head screw with hexag
55	G06650135	E07316	1	Tank cap
56	G06850008	E08488	1	Tank plug with O-ring
58	G06650364	E07574	1	Fuel valve right total
59	G00016007	E08490	1	Half shell (4 Stk.)
60	G00008080	E07600	1	Seal (4 Stk.)
68	G06650404	E07614	1	Hose clip (2 Stk.)
69	G06850009	E08491	1	Fuel hose (tank to filter)
111	G00009108	E08177	1	Hexagon screw with serration (3 Stk.)
112	G00010133	E12385	1	Disc
113	G00008145	E07287	3	Rubber bearing
135	G00007052	E07876	1	Connection nut (2 Stk.)
335	G07853001	E01965	1	Spring pin (20 Stk.)
336	G07853040	E08567	1	Spring pin
381	G07833020	E07642	1	Hexagon socket head cap screw (2 Stk.)
382	G06922028	E11588	1	Covering cap for handlebar
383	G06922027	E11587	1	Two-spoke steering wheel
386	G06850054	G06850054	1	Steering shaft

